Expires: 30 June 2025

# **Wright Brass Tech Rider**

# • Power Requirements

- All power to be used by the band must be vetted by a qualified electrician to be safe and functional prior to the band's arrival. Verify all wiring, grounding, and voltage/current draw is correct to ensure safety of musicians and production equipment.
- Please ensure that an electrician, technician, or otherwise qualified person will be available onsite to inform on power and unlock the power source, if applicable, upon the band's arrival.
- o Power sources must be within 25' of the performance area at maximum.
- o Four separate 20-amp 110-120 Volt circuits required at minimum.

#### Wireless

 If radios, wireless microphones, or any other wireless systems will be in use during the event, a wireless exclusion list detailing the specific frequencies your wireless equipment will occupy is required for radio frequency coordination.

#### Load-In

Please locate the most accessible loading dock and or entrance as close to the
performance area as possible to allow convenient unloading of our vans and or
box truck. Please ensure the area is available at the time the band is scheduled
to arrive and that the band's vehicles will be able to stay in place in the area until
load-out is completed after the performance.

## Stage Requirements

Our minimum stage size requirement is 24'x16', but 24'x20' with an 8'x8' drum riser is preferred. Please plan accordingly if the stage is to be shared.

## Mixing Position

 Ensure an 8'x8' area approximately 50' from the stage is available for a mixing position.

# • Green Room and Storage

 A room or space for the band to change into performance uniforms as well as store empty equipment cases is required. The spaces for changing and storage can be the same or separate.

# Timeframe

 Setup takes approximately one hour and a half with a one-hour teardown. Please ensure host facility and staff are aware of this to avoid any possible conflicts.